

# Alpha Miner 200 Series User Manual

**Description:** Alpha Miner 200 Series operating system is Linux Ubuntu 16.04. Nine AMD RX470/570 graphic cards are used for mining ETH, ETC, ZEC, XMR cryptocurrencies. You are free to mine any other compatible currency once you install proper software. To start mining please read through instruction below.


## Mining ETH, ETC, ZEC, XMR

At the desktop you can see different folders with software for different cryptocurrencies – ETH, ETC, ZEC, XMR



## Setting Up Your Wallet

Open the ETC, ETH, ZEC, or MXR folder and open file start.bash with Gedit:




Copy your ETH, ETC, ZEC, or XMR wallet address and pool address into proper fields:



After editing, close start.bash and run Terminal in the same folder (ETH, ETC, ZEC, XMR) by right clicking inside the folder:



Write ./start.bash command in the Terminal and press enter:



If everything is OK you will see stable miner work:

